











- •Each appliance requires its own 5kva transformer
- •Each transformer must be plugged into seperate 240v wall socket no 240v leads or not same socket.
- •32 amp 110v 4mm extension leads must be used up to a maximum of 4 leads per appliance.
- •Lift machine off floor before starting
- •Do not turn switch to run for longer than few seconds















